

Touch Up Instructions

Read these instructions in their entirety before attempting touch up on The Wood Series products from Allura Spectrum.

Consulte las instrucciones en español en el reverso.



Scan for Additional Technical Resources



PROUDLY FINISHED WITH
SHERWIN-WILLIAMS
COATINGS

Contents

The Wood Series touch up kit contains a bottle of The Wood Series touch up paint, an edge coat applicator, a paint pen applicator with applicator tip, and a small artists brush. Verify the color and accessories are correct and the kit is not damaged prior to use. Familiarize yourself with the components to ensure proper use of applicators for specific applications.

DO NOT use any paint products or applicators other than the ones supplied in this kit to touch up Allura Spectrum products.

Before Applying

Ensure the The Wood Series touch up paint is thoroughly mixed in the bottle and applicators before use. DO NOT thin the paint and avoid applying paint early or late in the day when condensation is likely to form, or when precipitation is expected. Apply The Wood Series touch up paint when air, surface, and material temperatures are 35°F (2°C) or greater and the surface is at least 5°F (3°C) above the dew point. DO NOT apply if air or surface temperatures are below 35°F (1.7°C) or when air or surface temperatures may drop below 35°F (2°C) within 48-hours. Ideal conditions for touch up are between 55-80°F (13-27°C).

Ideal storage conditions for The Wood Series touch up kits is 60-80°F (16-27°C).

DO NOT allow paint to freeze.

Surface Preparation

Remove cut dust, dirt, grease, and other surface contamination from The Wood Series product using a clean, dry, lint-free rag or cloth. Using one of the applicators, test The Wood Series touch up paint on a scrap piece to confirm color match prior to use.

Only apply The Wood Series touch up paint to clean dry surfaces.

Applying Allura Spectrum Touch Up Paint

Edge Coat Applicator: This applicator is to be used for sealing edge cuts only. Use on raw edges of board after cutting notches around windows, doors, and other penetrations, as well as termination cuts, and non-factory edge mid field butt joints. Sealing all cuts with the edge coater is required to seal the edges, make joints less visible, and protect the Allura substrate from moisture infiltration. Apply a liberal amount of paint to ensure full coverage on cuts.

This applicator is not to be used to touch up any blemishes, scratches, or small imperfections on the face of the product. Remove any excess paint that gets on the face of the board immediately using a clean, dry, lint-free rag or cloth.

Paint pen applicator: This applicator is to only be used for blemishes, scratches, or small imperfections. Any affected piece with larger or frequent blemishes should be removed and replaced. The included artist brush may be used if needed to blend in the touch-up paint with the unique look of The Wood Series. When applying the paint, confine the paint to the area that requires touch up only. When touching up nail heads paint should be applied to nail head only.

When used properly, this pen is designed to apply The Wood Series touch up paint sparingly. If using paint pen for the first time press the tip on a hard surface to allow the paint to flow. Repeat this step until the paint pen tip is saturated and paint is flowing evenly.

In all applications, remove any excess paint immediately using a clean, dry, lint-free rag or cloth. Excessive paint on the face of The Wood Series products poses the risk of loss of aesthetic appeal.



Drying

The Wood Series touch up paint normally dries in 30 minutes at 77°F (25°C) and 50% relative humidity. Drying time may vary based on temperature, humidity, color, film build and air movement.

Clean up

Clean hands and tools immediately with warm soapy water.

Instrucciones de retoque

Lea estas instrucciones en su totalidad antes de intentar retocar los productos The Wood Series de Allura Spectrum.



Scan for Additional
Technical Resources

PROUDLY FINISHED WITH
SHERWIN-WILLIAMS
COATINGS

Contenido

El kit de retoque incluye:

- Bote de pintura para retoque The Wood Series.
- Rotulador de pintura con puntas de repuesto.
- Aplicador de pintura para bordes.
- Pincel pequeño.

Verifique que el color y los accesorios sean correctos, que el kit no este dañado y que esté en buen estado antes de usarlo. Asegúrese de familiarizarse con los componentes para garantizar el uso correcto de los aplicadores para aplicaciones específicas.

Importante: NO utilice productos de pintura ni aplicadores distintos de los suministrados en este kit para retocar los productos Allura Spectrum.

Antes de aplicarlo

Asegúrese de agitar bien el envase de pintura y en los aplicadores antes de usarla. No diluya la pintura. Evite aplicar en horas del día donde haya riesgo de condensación o lluvia. Aplique la pintura cuando la temperatura ambiente y de la superficie sea de al menos 35°F (2°C) o más y la superficie esté al menos 5°F (3°C) por encima del punto de rocío.

NO aplicar si la temperatura del aire o de la superficie es inferior a 35°F (2°C) o si la temperatura del aire o de la superficie puede descender por debajo de 35°F (2°C) en 48 horas. Las temperaturas ideales para retoques son entre 55-80°F (13-27°C).

Almacenamiento: Mantenga los kits de retoque en un lugar seco, entre 60-80°F (16-27°C), evitando que la pintura se congele.

Preparación de la superficie

Limpie bien la superficie con un paño limpio y seco que no suelte pelusa. Asegúrese de que la zona esté libre de polvo, grasa o cualquier suciedad. Antes de empezar, pruebe la pintura en un pedazo de material de desecho para confirmar la coincidencia del color.

Solo aplique la pintura en superficies limpias y secas.

Aplicación de la pintura de retoque

Aplicador de pintura para bordes: Este aplicador debe usarse únicamente para sellar cortes en los bordes después de recortes alrededor de ventanas, puertas y otras penetraciones. También para uniones en bisel o cortes de campo medio que no sean de fábrica. Aplique suficiente pintura para cubrir completamente el borde y evitar la entrada de humedad. Limpie cualquier exceso de inmediato con un paño limpio y seco.

Nota: No use este aplicador para retocar rayones o manchas superficiales.

Rotulador de pintura: Utilice el rotulador únicamente para pequeñas imperfecciones, rayones o detalles mínimos. Cualquier pieza afectada con imperfecciones más grandes o frecuentes debe retirarse y reemplazarse. Al aplicar la pintura, límitela a la zona que requiere retoque. Al retocar las cabezas de los clavos, la pintura debe aplicarse solo en la cabeza del clavo. Si es necesario, use el pincel de artista para difuminar la pintura y lograr un acabado más natural.

Cuando se usa de manera apropiada, este rotulador está diseñado para aplicar pintura de retoque de manera moderada. Al utilizar el rotulador por primera vez, presione la punta sobre una superficie dura para que la pintura fluya. Repita este paso hasta que la punta del rotulador esté saturada y la pintura fluya uniformemente.

En todas las aplicaciones, elimine inmediatamente cualquier exceso de pintura con un trapo o paño limpio y seco que no suelte pelusa. Un exceso de pintura en la superficie de los productos supone un riesgo de pérdida de atractivo estético.

Secado

La pintura se seca normalmente en aproximadamente 30 minutos a 77°F (25°C) y 50% de humedad relativa. El tiempo puede variar según la temperatura, humedad, movimiento del aire y grosor de la capa aplicada.

Limpieza

Lávese las manos y limpie las herramientas con agua caliente y jabón una vez finalizado el trabajo.

